

HIGH-PERFORMANCE AIR SYSTEMS

Variable Air Volume Diffusers



ACUTHERM BY PRICE VAV DIFFUSER SYSTEMS

High-performance air systems demand modern design approaches with leading-edge products and technology in order to optimize comfort and reduce energy consumption.

A comfortable environment is achieved by providing the smallest possible zones of temperature control, allowing for individual temperature distribution and better air movement. Reduction in energy is realized by designing a low-pressure HVAC system that allows for maximum turndown while maintaining temperatures.

ACUTHERM BY PRICE VAV DIFFUSER SYSTEMS PROVIDE:



Comfort

With each VAV diffuser acting as an individual zone of control, every area of a building can have separate, optimized temperature settings. The individual occupant selects a personal comfort setting, and average temperature is maintained within 1.5°F/0.9°C. Acutherm by Price VAV diffusers provide a constant discharge velocity with improved comfort as a result of higher throw, no dumping, improved room air movement and uniform temperature distribution.



Energy Savings

Acutherm by Price VAV diffusers allow for low-pressure, low-energy consumption systems. Our energy-efficient VAV diffuser systems prevent overcooling and overheating – resulting in 10%–47% energy savings when compared to other HVAC systems. Energy savings is produced from three sources: small zones, low turndown and pressure drop and low system pressure.



Sustainability


Sustainable buildings are designed to be environmentally responsible and resource efficient throughout their life cycle. For sustaining long-term usefulness, Acutherm by Price's VAV diffuser systems are exceptionally adaptable to office changes. No diffuser zone is split when office walls are put up or moved. The modular concept and flexibility provided by a VAV diffuser system guarantees that any changes in the floor plan need not trigger expensive and disruptive changes to the HVAC system.

COMFORT

Personal thermal comfort stems from appropriately sized zones of control. Creating many small zones provides exceptional levels of control, leading to outstanding occupant comfort.

Individual Thermostat Control

VAV diffusers are a cost-effective and practical way to provide this level of personalized control. Each VAV diffuser has an individual thermostat and built-in damper, allowing it to act as an individual VAV zone of control. The damper is continuously adjusted to vary the volume of airflow (warm or cold) into the room in response to room temperature and set point.



ACUTHERM



Individual preferences are met, resulting in comfort for all occupants




As loads shift, the units automatically modulate the damper to properly supply each space and ensure energy efficiency


Better Room Air Mixing

With an adjustable damper built right in, VAV diffusers are able to enhance occupant comfort by varying the discharge opening as they vary air volume. The result is an almost-constant discharge velocity, with the benefits of a better throw, no dumping, a higher level of room air movement and a uniform temperature distribution, even at low supply air volumes.

Room Mixing Comparison

Computational fluid dynamics (CFD) analysis shows effective room air mixing with the VAV diffuser both at 100% open (top) and at 25% open (bottom).





ENERGY SAVINGS



Savings from Three Sources

VAV diffusers allow for low-pressure, low-energy consumption systems. The energy savings of systems designed using VAV diffusers can be broken down into three main sources:

- Small zones
- Low turndown and pressure drop
- Low system pressure

Small zones

Many small zones provide individual temperature control to prevent overcooling or overheating when spaces are unoccupied.

Low turndown and pressure drop

VAV diffuser systems do not have a velocity limitation because pressure independence is achieved by measuring only static pressure. The static pressure damper in a VAV diffuser system may be oversized to minimize pressure drop without the penalty of increasing minimum flow.

Low system pressure


VAV diffuser systems require low duct pressure, which reduces the required fan horsepower and, in turn, the energy required to operate the system.

Low Pressure Drop Comparison

Compared to other systems, the low-pressure, low-energy systems designed around VAV diffusers require less fan horsepower and prevent the overcooling and overheating of spaces. The example below shows 33% energy savings compared to traditional VAV box systems.

TRADITIONAL VAV BOX SYSTEM

VAV DIFFUSER SYSTEM



33% FAN ENERGY SAVINGS

SUSTAINABILITY _____


Enduring Ease-of-Use

Acutherm by Price VAV diffusers have a long life span and offer simple maintenance. Thermally powered units do not require any wiring and, aside from set point adjustment, are virtually maintenance free with 45+ years of proven operation. Motorized diffusers make use of long-life brushless motors to reduce maintenance requirements and provide near-silent operation.




Future-Proof Flexibility

VAV diffuser systems are exceptionally adaptable to office changes. The modular concept and flexibility provided by a VAV diffuser system means that any changes to the floor plan need not trigger expensive and disruptive changes to the HVAC system.




FUNCTIONALITY



Each VAV diffuser is a ceiling diffuser with an individual thermostat and built-in VAV damper, allowing it to act as an individual VAV zone of control. The damper is continuously adjusted to vary the volume of airflow (warm or cold) into the room in response to room temperature and set point. When supply air is warm, the VAV diffuser operates in heating mode, and the damper opens in response to a drop in room temperature. When the supply air is cold, the VAV diffuser operates in cooling mode, and the damper opens in response to a rise in room temperature.

Separate room temperature set points for heating and cooling are individually adjustable and average temperature is maintained within 1.5°F/0.9°C.



Thermostat and actuator – contains a blend of petroleum distillate waxes; the waxes melt and expand, driving a piston with a precise movement per degree temperature change


As with all diffusers, air circulates around the room in a circular motion. Secondary air rises under the diffuser, passes beneath the diffuser plaque and entrains with the primary air at the outside edge of the diffuser. This secondary air best represents average room temperature.

To monitor average room temperature, a continuous sample of secondary air is drawn around the plaque past the room thermostat(s). This is accomplished by feeding primary air through venturi nozzle(s). Primary air blowing through the nozzle(s) creates just enough vacuum to draw some secondary air around the plaque, over the thermostat(s) and out the other side.




For electric diffusers, quiet, long-life, brushless motors provide repeatable and reliable control

Positive induction mechanism – a continuous sample of room air drawn over the individual thermostats



The high velocity discharge from the diffuser entrains room air into the supply air resulting in a rising column of room air under the diffuser. A small amount of supply air passed through a venturi nozzle creates an area of low pressure in the diffuser that induces a sample of room air over the thermostat. Room air is positively induced over the thermostat independent of diffuser damper postion.





SYSTEM OPTIONS

	THER	RMAL	ELEC	TRIC	HYE	RID
FEATURES	Therma-Fuser stand-alone thermally powered VAV diffusers	Therma-Fuser diffusers + wall adjuster + room temperature sensor	Advantage stand-alone electric motor VAV diffusers	Interoperable BACnet building network VAV diffusers	Therma-Fuser VAV diffusers	Interoperable VAV diffusers
Individual temperature control, superior air distribution, energy- saving adaptable system	✓	✓	✓	✓	✓	✓
No diffuser maintenance	✓	✓			✓	
No diffuser wiring	✓					
BAS only monitors parts of system requiring periodic maintenance	✓					
Monitors room air temperature		✓	✓	✓		✓
Monitors and adjusts room temperature set points		✓	✓	✓		✓
Monitors diffuser supply air temperature			✓	✓		✓
Monitors diffuser supply air volume			✓	✓		✓
Network protocol		Analog	BACnet	BACnet		BACnet
Other network functions			✓	√		✓
Diffuser power	Thermal	Thermal	Electric motor	Electric motor	Thermal	Electric motor
Installed cost	\$	\$\$	\$\$	\$\$\$	\$	\$
Warranty*	10 year	10 year	2 year	2 year	10 year	2 year
*Not applicable to options and accessories						

*Not applicable to options and accessories

TYPICAL ZONES & VAV DIFFUSER SYSTEM OPTIONS

A comfortable environment can be provided with many different strategies. The zones shown are generalized examples of typical configurations you will find in many of today's built environments. These examples demonstrate some of the many products and options available and how Acutherm by Price can fit into each particular zone.

3 SMALL ZONE OF CONTROL TF/ST and TL Mechanical (Thermal) Diffusers

- Individual thermostat, individual set points for each occupant
- Option ADJ or Disi
- Allow the occupant to easily adjust the temperature set point

4 SMALL ZONE OF CONTROL – NETWORKED EF and EL Digital (Electric) Diffusers

- Individual thermostat, individual set points for each occupant
- BACnet networking with building automation system


1 STATIC PRESSURE CONTROL PIM Pressure Independence Module

- Provides static pressure control as diffusers open and close
- Systems with a constant-volume fan may use the PIM as a bypass

2 DUCT HEAT

Acu-Zone Hot Water or Electric Duct Heaters


 Provides constant supply air temperature at design and low airflow rates



and close

as a bypass

EXAMPLE ZONE: OPEN OFFICE




19

TYPICAL ZONES & VAV DIFFUSER SYSTEM OPTIONS

and close

as a bypass



TYPICAL ZONES & VAV DIFFUSER SYSTEM OPTIONS



TYPICAL ZONES & VAV DIFFUSER SYSTEM OPTIONS

and close

2 DUCT HEAT



VAV DIFFUSER PRODUCTS



2 x 2 ft. Square Diffuser with Blade Damper

(24 in / 600 mm square)

Therma-Fuser Series – TF / Interoperable Series – EF

Four-blade dampers provide superior throw with 66 linear inches of variable discharge area.

Inlet diameter	6/8/10/12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	100 to 720 CFM	45 to 340 l/s
Throw¹	3/4/6 to 12/14/17 ft.	0.9/1.2/1.7to 3.6/4.2/5.1 m
Noise ²	<15 to 34 NC	<15 to 34 NC



2 x 2 ft. Square Diffusers with Disc Damper

(24 in. / 600 mm square

Therma-Fuser Series – ST

Easy adjustment minimum flow dial. One stop lever for balancing.

Inlet diameter	6/8/10/12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	105 to 740 CFM	50 to 350 l/s
Throw ¹	<1/1/3 to 9/11/13 ft.	<0.3/0.3/0.9 to 2.7/3.4/4.0 m
Noise ²	<15 to 38 NC	<15 to 38 NC



Linear Diffuser - Ceiling, Wall, Individual or Continuous

Therma-Fuser Series – TL / Interoperable Series – EL

Advantage Series – ADVL

Elegant linear design for individual units or continuous linear slots.

VAV diffusers with streamlined aluminum extrusions to provide a slim archi-

tectural shape. Ce	eiling and sidewall a	pplications.
Length	24/36/48/60 in.	600/900/1200/1500 mm
Slots	Multiple slots and blow patterns available	
Pressure ranges	0.05 to 0.25 in.w.g. 12 to 62 Pa	
Air volumes	45 to 960 CFM 20 to 455 l/s	
Throw¹	2/3/4 to 25/33/40 ft.	0.6/0.9/1.2 to 7.6/10.0/12.2 m

<15 to 42 NC



2 ft. Round Diffuser with Disc Damper

(24 in. / 600 mm round

Advantage Series – ADVR

The pleasing round shape blends in with round architectural features or exposed round duct work.

Inlet diameter	6 / 8 / 10 / 12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	120 to 720 CFM	59 to 340 l/s
Throw¹	3/4/7 to 10/12/17 ft.	0.9/1/1.2/2 to 3.0/3.7/5.2 m
Noise ²	<15 to 42 NC	<15 to 42 NC



2 ft. Round Diffuser with Disc Damper

(24 in 7600 mm round)

Therma-Fuser Series – STR

With all the performance and air distribution of the ST, the round model has been developed for aesthetic consideration.

Inlet diameter	6/8/10/12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	105 to 740 CFM	50 to 350 l/s
Throw¹	<1/1/3 to 9/11/13 ft.	0.3<0.3 /0.9 to 2.7/3.4/4.0 m
Noise ²	<15 to 38 NC	<15 to 38 NC



1 x 1 ft. Square Diffuser with Blade Damper

(12 5/8 in / 320 mm square)

24

Therma-Fuser Series – TK

Specially designed for small task conditioning. Four-blade damper provides superior throw.

Inlet diameter	6 in.	150 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	115 to 265 CFM	55 to 125 l/s
Throw ¹	4/6/8 to 8/10/13 ft.	1.2/1.7/2.5 to 2.5/3.0/4.0 m
Noise ²	<15 to 37 NC	<15 to 37 NC



2 x 2 ft. Square Diffusers with Disc Damper

<15 to 42 NC

(24 in. / 600 mm square)

Advantage Series – ADV

Designed to provide a greater range of operation and increased speed of response required by some projects.

Inlet diameter	6/8/10/12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	115 to 730 CFM	54 to 344 l/s
Throw¹	4/6/10 to 9/12/16 ft.	1.2/1.8/3.0 to 2.7/3.7/4.9 m
Noise ²	<15 to 40 NC	<15 to 40 NC



2 x 2 ft. Swirl Face Diffuser with Disc Damper

(24 in. / 600 mm squar

25

Advantage Series – ADVS

The swirl face provides a modern, aesthetically pleasing appearance combining a high-induction geometry with a VAV damper.

Inlet diameter	6/8/10/12 in.	150/200/250/300 mm
Pressure ranges	0.05 to 0.25 in.w.g.	12 to 62 Pa
Air volumes	130 to 525 CFM	61 to 248 l/s
Throw ¹	1/2/4 to 5/8/12 ft.	0.3/0.6/1.2 to 1.5/2.4/3.7 m
Noise ²	<15 to 41 NC	<15 to 41 NC

 $^{1}Throw$ at $\nu_{t} = 150$ / 100 / 50 FPM / 0.25 / 0.50 / 0.75 m/s

 2 Noise based on $L_w(10^{-12} \text{ watts reference}) - 10 dB$

 $^{1} Throw at v_{t} = 150 / 100 / 50 FPM / 0.25 / 0.50 / 0.75 m/s$ $^{2} Noise based on L_{\omega}(10^{-12} watts reference) - 10 dB$

BLOW PATTERNS

Custom air-blow patterns are available for most models. Contact Acutherm for additional information.









Blow

Opposite








Blow Corner

Linear Therma-Fuser Diffuser




1-Slot 1-Way





2-Slot 2-Way


2-Slot 1-Way



4-Slot 1-Way

4-Slot 2-Way

OPTIONS & ACCESSORIES



DMSA Airflow Measurement for Advantage Series Diffusers

The Diffuser Measuring Station (DMSA) is an optional addition to the Advantage VAV diffuser providing airflow measurement at each Advantage master diffuser.



Wall Adjusters and Thermostats

Therma-Fuser Series - DISIO Display Adjuster, Digital Wall Adjuster and Wireless Wall Adjuster

Interoperable Series – BACnet Wall Adjuster Advantage Series – TSTAT*

Acutherm by Price's Wall Adjusters for VAV diffusers allow the occupant to easily adjust the temperature set point. The Wall Adjuster is available in a wired or wireless model. Wall Adjusters are easily integrated to BAS with a protocol-independent interface. Acutherm by Price's thermostats for Advantage and Interoperable series diffusers provide both room temperature and occupant adjustable room temperature set point.

*There are several options for the Advantage, including LCD display, occupancy and CO₂ sensors.




Acutherm Pressure Relief Collar and Relief Ring

All Models

The Acutherm Pressure Relief Collar and Relief Ring are both inexpensive solutions when duct pressures are higher than desired. When the diffuser reduces the air flow into the room, these devices bypass the excess air into the plenum return system. Relief Rings are smaller than Relief Collars but are limited to 6, 8 and 10 in. inlets.


	Inlet sizes	Height
Relief ring	6/8/10 in. 150 / 200 / 250 mm	3 1/4 in. 121 mm
Pressure relief collar	6/8/10/12 in. 150 / 200 / 250 / 300 mm	8 in. 203 mm



Ceiling Approaches

All Models

Acutherm offers a variety of ceiling frames to suit most ceiling types. Diffusers installed in special ceilings should be installed such that obstacles are not below the plane of the diffuser casing extended. Breaking this plane risks breaking Coanda and could allow primary air to drop.



Static Pressure Control

All Models

The Acutherm Pressure Independence Module (PIM) helps VAV diffuser to operate quietly at both full flow and turndown conditions by providing pressure independence as either a modulating bypass or zone damper. It can be supplied with or without a damper, square/rectangular opposed blade or round damper with peripheral gasket. Tested to ASHRAE 130 and AHRI 880.




Acu-Zone Electric Zone Heater

Therma-Fuser Series – AZON-I-E & AZON-II-E

The Acu-Zone electric zone heaters use a patented airflow sensor and the most advanced modulating SCR (silicon controlled rectifier) proportional heat controller to vary the electrical power through the coil.

Electric heating units are available in round, square and rectangular sizes.

Control	SCR	SCR	
Inlet/outlet diameter	Round, rectangular or square		
Heating	Up to 21 kW/sq. ft.	up to 226 kW/m²	
Air volumes	Varies by size		
Power	Varies by size		



Acu-Zone Hot Water Zone Heater

Therma-Fuser Series – AZON-II-W

The Acu-Zone hot water zone heaters use a modulating PI (proportional/ integral) heat controller to vary the hot water through the coil and prevent excessive valve cycling.

Control	PID	PID
Valve ¹	PICCV or CCV	PICCV or CCV
Coil inlet diameter ²	6/8/10/12/14/16 in.	150/200/250/300/350/400 mm
Coil heating ²	5 1 to 111.6 MBH	17.4 to 380.9 kW
Coil air volumes ²	200 to 3300 cfm	94 to 1557 l/s

¹Optional pressure-independent, two-way or three-way valve

²Optional one- or two-row coil

SYSTEM DESIGN

The Acutherm by Price VAV diffuser is a simple stand-alone or networked device that provides VAV control when supplied with air in a suitable range of temperature and pressure.

Supply Air Temperature

When supplied with cool air, the VAV diffuser dampers modulate open on a rise in room temperature. When supplied with warm air, the dampers open on a room temperature drop.

Cool air should be a constant temperature not less than 50°F/10°C for standard models and warm air at a constant temperature of not more than 120°F/49°C. The constant discharge velocity of VAV diffusers at varying airflows provides good room circulation, which reduces stratification. Keeping heating supply air temperatures as low as possible will further reduce room air stratification to a negligible level.

Changeover from cooling to heating occurs as the supply air rises from 76°F/24.5°C to 80°F/26.5°C and change back from heating to cooling occurs when the supply air drops from 72°F/22°C to 68°F/20°C.

Static Pressure

Noise level at any air diffuser is influenced by air velocity through the diffuser, which is, in turn, a function of static pressure in the neck of the diffuser. Noise level at a VAV diffuser will not increase as it closes if the static pressure in the neck is held constant. As static pressure in the neck increases, sound level increases.

Static pressure at the inlet of the VAV diffuser must be high enough (0.05 in.w.g. /12 Pa or more) to obtain the required air volume for room air induction. Static pressure above 0.25 in.w.g. / Pa may cause the sound level to become noticeable (NC35).

Performance Requirements:

Supply Air Temperature

- + Constant temperature. May be reset to another constant temperature.
- + Cooling between 50°F/10°C and 68°F/20°C.
- → Heating between 80°F/26.5°C and as low as possible but not to exceeding 120°F/49°C.

Static Pressure

- → High enough for required air volume. No lower than 0.05 in.w.g. / 12 Pa.
- → Below rated static pressure for design sound level.

 No higher than 0.25 in.w.g. / 62 Pa suggested.

Location

Because VAV diffusers control room temperature by sensing room air induced up the center of the space, care should be taken not to disturb room air induction and entrainment. For example, location next to walls or dropped lights results in the reflection of primary air back at the VAV diffuser. Relocate either the VAV diffuser or use directional blow baffles.

Duct Design

The goal of a high-performance duct design is to design for lowest possible static pressure while providing ample air to each space. For example, if Therma-Fuser diffusers are to deliver nominal volume at inlet SP of 0.15 in.w.g. / 37 Pa, and if a maximum SP of 0.25 in.w.g. / 62 Pa is to be held for quiet operation, size the duct for a maximum pressure drop of 0.1 in.w.g. / 25 Pa between the first and last takeoff.

Manual balancing dampers should be used at the takeoff for each diffuser. Manual balancing dampers may not be required with ducts designed to Acutherm by Price specifications.

SYSTEM DESIGN CHECKLIST

Note: This is a general checklist. For detailed recommendations about specific systems, visit www.acutherm.com.

JOB NAME _____

1. DIFFUSER SIZE AND LOCATION

- Air volume sufficient for rooms needs. Correct inlet sizing for available static pressure.
- All VAV diffusers within 2 ft. of wall equipped with three-way blow away from wall.
- Multiple VAV diffusers in same room space no less than two times the 150 fpm / 0.76 m/s throw; use three-way blow if closer.

•	with the vav diffusers in same room – space no less than two times the 150 lpm / 0.76 m/s throw; use three-way blow it closer.			
2.	SUPPLY AIR TEMPERATURE - Cooling minimum 50°F/10°C Heating maximum 120°F/49°C			
	Changeover: To heating 80°F/26.5°C			
_	To cooling 68°F/20°C			
•	Source of cooling:			
	Chillled water AHU DX			
•	Source of heating:			
	AHU heat Gas Hot water Electric Steam			
	Duct heat			
	Heat pump			
	near pump			
	Separate perimeter heat – Baseboard Radiant panels Separate duct			
•	Portions of building in one master zone:			
	One exterior Note: Separate master zones are preferred for the interior and each exposure			
	More than one exterior			
	More than one extend			
	Heat pump			
	Other			
•	Source of cooling:			
•				
	Fan runs continuously			
•	Location of thermostat (or BMS sensor) used to control the AHU water valves or DX compressor:			
	Note: Do not use a return air thermostat (sensor)			
	System using some Therma-Fuser diffusers and some fixed opening			
	Room thermostat or sensor located in room of highest heating and cooling load. Fixed opening diffuser used in this room.			
	Complete System			
	Preferred approach – supply air control / room changeover			
	Supply air temperature controlled by discharge air thermostats (sensors)			
	Mode selected by changeover thermostat (sensor) in the room. Therma-Fuser diffuser with minimum flow stops in this room			

SYSTEM DESIGN CHECKLIST

Note: This is a general checklist. For detailed recommendations about specific systems, visit www.acutherm.com.

3.	STATIC PRESSURE — Inlet minimum 0.05 in.w.g. / 12 Pa or high enough for required air volume. Inlet minimum 0.05 in.w.g. / 62 Pa for NC 35 or less.			
•	Control:			
	Less than 30% turndown of system air – static pressure control usually not necessary.			
	Over 30% turndown of system air.			
	Static pressure control with:			
	Fan control			
	Variable speed drive Other			
	Zone control damper	Static pressure sensor		
	Bypass Acutherm PIM	located two-thirds or		
		three-quarters of the equivalent duct length		
	Damper	between control and end		
	R-rings: use only with ceiling plenum return	of duct.		
	Both fan and zone control			
•	Duct Design: Supply:			
	Static pressure no higher than 0.25 in.w.g. / 62 Pa at the first takeoff downstream from the static	oressure control		
	Static pressure no higher than 0.25 m.w.g. / 02 f a at the mst takeon downstream from the static pressure control.			
	Sufficient static pressure at the last VAV diffuser to obtain the required airflow. Size last VAV diffus achieve required flow.	ers larger to		
•	 Zone dampers are necessary where pressure losses in ducts are too high. Manual balancing dampers should be used at the takeoff for each diffuser. Manual balancing dampers may not be required with ducts designed to Acutherm specifications. 			
	Return:			
	Ceiling plenum One return for each diffuser preferred.			
	Ducted Minimum of one return per room.			
	Other			



ACUTHERM HEADQUARTERS

6379 Clark Ave Suite 280 Dublin CA 94568 USA

Main: +1 510 785 0510 Email: info@acutherm.com

Product improvement is a continuing endeavor at Acutherm. Therefore, specifications are subject to change without notice. Consult your Acutherm Sales Representative for current specifications or more detailed information. Not all products may be available in all geographic areas. The complete product offering can be viewed online at acutherm.com.

